

Texas TeleSys, Inc.

Your Telecom Solution! 512.468.8392

Setup Basic Night Service

**First, to determine the Voice Mail Mailbox #: Press Feature 985
-write down this number.**

--Then--

Feature **266344

Log: (Password) 266344

System Displays Terminals & Sets

Press NEXT 2 Times.

System Displays Services

Press SHOW.

System Displays Ringing Service

Press SHOW.

System Displays Ringing Groups

Press SHOW.

System Displays Show Group:

Enter Group 001.

System Displays Ring Group:001, Press SHOW.

System Displays Show Set:

Enter Voice Mail ID #. (From above Feature 985).

System Displays <VM#>:NoAssigned, Press CHANGE to Assign.

Press HEADING Button (line 1) 2 times.

System Displays Ringing Groups, Press NEXT.

System Displays Sched: Night, Press SHOW.

System Displays Service: <Manual>, Press NEXT.

System Displays Trunk Answer: Y , Press NEXT.

System Displays Extradial: <21>, Press NEXT.

System Displays Line Settings, Press SHOW.

System Displays Show Line:, Enter line 001.

System Displays Line001:Line001, Press SHOW.

System Displays Ring Group:001, Press HEADING Button (line 1).

System Displays Line001:Line001, Press NEXT.

System Displays Line002:Line002

* Follow same instructions for lines 2, to make sure it is set on Ring

Press Change until system displays line that you want picked up.

Hit Release to end.



Please call if you have any questions.