

Texas TeleSys, Inc.

Your Telecom Solution! 512.468.8392

Changing a LINE Name

To enter a programming session, follow the next few simple steps:

1) Press FEATURE * * 2 6 6 3 4 4

2) Enter Password: 2 6 6 3 4 4

Display will read: "**Terminals & Sets**"

Using the navigation keys, as displayed below, follow the next simple steps:



3) Press: **NEXT**

Display will read: "**Lines**"

4) Press: **SHOW**

Display will read: "**Show Line: _ _**"

5) Enter the line number you wish to re-name. **Example: 001(Line 1)**

Display will read: "**Line 001:Line 001**"

6) Press: **SHOW**

Display will read: "**Trk/Line data**"

7) Press: **NEXT**

Display will read: "**Name: Line 001**"

8) Press the **CHANGE** softkey

Using the dial-pad, press the button associated with the letter you wish to be displayed. For example: If you wish to name the "MAIN1", you would simply press the 6 key on the dial-pad until the "M" is displayed. To advance to the next letter, press the "#" key.

Once you have the new LINE NAME displayed, press *NEXT* to save it.

To exit the programming session, press the *RLS* key.

Congratulations! You now have learned how to program a Line Name!