

Texas TeleSys, Inc.

Your Telecom Solution!

512.468.8392

To Change Message Notification

Log Into Your Mailbox And Press 8

Then: 6 Message Notification
Options

Press

Admin or 1 to change Message Notification

Setup or 1 to change the 1st notification number

Press Line or 1 to select a line.
Pool or 2 to select a pool
IC or 3 to select an Intercom

Press Chng or 1 If you do not want to change the Line,
Pool, or Intercom Press
OK.

Enter <the new line, pool or intercom>

Press

OK or # to end the number

Press OK or # to accept the line, pool or intercom.

Press

CHNG or 1 to change the Destination number.

Enter <the new destination telephone number >

Press

OK or # to end the telephone #.

Press

OK or # to accept the telephone #.

Press CHNG or 1 to change the destination Type

