

Texas TeleSys, Inc.

Your Telecom Solution!

512.468.8392

Changing Number of Rings before AA

Feature 983

Log: (Password)

See Below

For 2 Digit Extensions

120000

For 3 Digit Extensions

1020000

For 4 Digit Extensions

10020000

System Displays Admin

Press AA.

System Displays Auto Atdt Admin
GRTG TABLE LINES

Press LINES.

System Displays Line number:
RETRY OK

Enter <the line number>

Press OK.

System Displays Line: 1 Ans: Y
CHNG TABLE OK

Press TABLE.

Press RINGS.

System Displays Line: 1 Rings: 0
CHNG ANS OK

Press CHNG.

System Displays No. of rings:
RETRY OK

The number of rings ranges from zero to 12. Repeat steps to continue entering the number of rings for each incoming line.

Press *. -- Goes back to previous menu to start over with Line 2 and others.

Please call if you have any questions.