

# **Texas TeleSys, Inc.**

**Your Telecom Solution!      512.468.8392**

## **Changing the Ring type of your phone**

To enter a programming session, follow the next few simple steps:

Press FEATURE \* 6 (your current ring setting will immediately become audible)

To change your ring setting...

There are (4) Ring settings to choose from

Press 1, 2, 3 or 4 for the desired setting.

As you press the numeric key, the associated ring will become audible.

Press the OK softkey to select the desired ring.