

# Texas TeleSys, Inc.

Your Telecom Solution! 512.468.8392

## Allowing a phone to redirect a Line

To enter a programming session, follow the next few simple steps:

1) Press FEATURE \* \* 2 6 6 3 4 4

2) Enter Password: 2 6 6 3 4 4

Display will read: "**Terminals & Sets**"

Using the navigation keys, as displayed below, follow the next simple steps:



3) Press: *SHOW*

Display will read: "**Show Set**"

Enter the extension number that you wish to allow the redirect feature. (Example: 221)

4) Press: *SHOW*

Display will read: "**221:Operator**"

5) Press: *SHOW*

Display will read: "**Line Access**"

7) Press: *NEXT*

Display will read: "**Capabilities**"

8) Press: *SHOW*

Display will read: "**Fwd no Answer**"

9) Press: *NEXT* until the display reads "**Allow redirect: N**"

10) Press the *CHANGE* softkey until the display reads: "**Allow redirect: Y**"

**11)** Press: *NEXT*

Display will read: "**Redirect ring: N**"

**12)** Press the *CHANGE* softkey until the display reads: "

**13)** Press: *NEXT*

Congratulations! You have successfully changed your redirect line allowance!