

Texas TeleSys, Inc.

Your Telecom Solution! 512.468.8392

Setting the "Prime Line" on your phone

To enter a programming session, follow the next few simple steps:

1) Press FEATURE * * 2 6 6 3 4 4

2) Enter Password: 2 6 6 3 4 4

Display will read: "**Terminals & Sets**"

Using the navigation keys, as displayed below, follow the next simple steps:



3) Press: *SHOW*

Display will read: "**Show set: __**"

4) Enter the Extension number of which you wish to add a line. **Example: 21**

Display will read: "**21:21**"

5) Press: *SHOW*

Display will read: "**Line access**"

6) Press: *SHOW*

Display will read: "**Line assignment**"

7) Press: *NEXT* until it the display reads "**Prime Line: none**"

8) Press the *CHANGE* softkey until you see the desired prime line setting displayed.

Congratulations! You now have learned to program the Prime Line on your phone!